



ITEM	DESCRIPTION
1	USER INTERFACE
2	TERMINAL BOARD
3	PUMP POWER TERMINALS (TB1)
4	TRANSFORMER (3PH ONLY)
5	OVERLOAD(S) (3PH ONLY)
6	CIRCUIT BREAKER(S) (NOT SHOWN)
7	MOTOR CONTACTOR(S)
8	TEST/SILENCE/RESET SWITCH
9	FUSES & FUSE HOLDERS
10	GLOBE
11	ALARM BUZZER