Trusted. Tested. Tough.®

ZOELLER® PUMP COMPANY

MAIL TO: P.O. BOX 16347 • Louisville, KY 40256-0347
SHIP TO: 3649 Cane Run Road • Louisville, KY 40211-1961
Tel: (502) 778-2731 • 1 (800) 928-PUMP

Visit our website:
zoellerpumps.com

CL0023
0224
Supersedes
0223

Product information presented here reflects conditions at time of publication. Consult factory regarding discrepancies or inconsistencies.

Turbine STEP Float Trees

TECHNICAL SPECIFICATIONS

A Convenient Assembly For Organizing Float Switches Inside A Turbine Step Vault.


Zoeller Pump Company float trees feature snap-on and twist-and-grip holder technologies.

Features

- Various float tree lengths to match STEP vault heights
- Two to five hanger float trees are available
- Easy to install and remove for maintenance
- Designed for use in turbine STEP system applications
- Twist-and-grip technology to secure and tether the float cord

Turbine STEP Float Trees	
Part Number	**Description**
10-1672	2-Hanger Float tree, 60"
10-1673	3-Hanger Float tree, 60"
10-1674	4-Hanger Float tree, 60"
10-1726	5-Hanger Float tree, 60"
10-1741	3-Hanger Float tree, 84"
10-1746	3-Hanger Float tree, 96"
10-1792	3-Hanger Float tree, 51"
10-1793	4-Hanger Float tree, 96"
10-1932	2-Hanger Float tree, 72"
10-1933	2-Hanger Float tree, 96"
10-2136	2-Hanger Float tree, 51"
10-2152	4-Hanger Float tree, 120"
10-2180	4-Hanger Float tree, 90"
10-2196	4-Hanger Float tree, 72"
10-2209	4-Hanger Float tree, 84"
10-2260	4-Hanger Float tree, 51"





sk2415

Floats not included.

© Copyright 2024 Zoeller® Co. All rights reserved.