

Trusted. Tested. Tough.®



3.20.310
CL0097
1023
Supersedes
0123

MAIL TO: P.O. BOX 16347 • Louisville, KY 40256-0347
SHIP TO: 3649 Cane Run Road • Louisville, KY 40211-1961
Tel: (502) 778-2731 • 1 (800) 928-PUMP

Visit our website:
zoellerpumps.com

Product information presented here reflects conditions at time of publication. Consult factory regarding discrepancies or inconsistencies.

Technical Data


Automatic Multizone Valves



6000 Series



4000 Series




Pre-assembled unit with unions and shut-off valve

For use in residential & small commercial disposal fields

Features

- Easy to install
- Easy to maintain
- Exceptional reliability
- Preassembled units with unions, piping, and shut-off valve are available
- Models available for splitting flows through 2, 3, 4, 5, or 6 zones



SK2470

Automatic Multizone Valve	
Part Number	Description
170-0064	Model 4402 - for 2 zone operation
170-0065	Model 4403 - for 3 zone operation
170-0066	Model 4404 - for 4 zone operation
170-0067	Model 4605 - for 5 zone operation
170-0068	Model 4606 - for 6 zone operation
170-0069	Model 6402 - for 2 zone operation
170-0070	Model 6403 - for 3 zone operation
170-0071	Model 6404 - for 4 zone operation
170-0072	Model 6605 - for 5 zone operation
170-0073	Model 6606 - for 6 zone operation
5053-0001	2 Outlet multizone assembly (with unions, piping, and shut-off valve)
5053-0002	3 Outlet multizone assembly (with unions, piping, and shut-off valve)
5053-0003	4 Outlet multizone assembly (with unions, piping, and shut-off valve)
5053-0004	5 Outlet multizone assembly (with unions, piping, and shut-off valve)
5053-0005	6 Outlet multizone assembly (with unions, piping, and shut-off valve)
019136	2-Zone cam for 6400 series multizone valves
019137	3-Zone cam for 6400 series multizone valves
019138	4-Zone cam for 6400 series multizone valves
019139	5-Zone cam for 6600 series multizone valves
019140	6-Zone cam for 6600 series multizone valves