Patent No. D740329



SECTION: 2.65.014 FM3165 0925 Supersedes 0724

MAIL TO: P.O. BOX 16347 • Louisville, KY 40256-0347 SHIP TO: 3649 Cane Run Road • Louisville, KY 40211-1961 Tel: (502) 778-2731 • 1 (800) 928-PUMP

Visit our website: zoellerpumps.com

Product information presented here reflects conditions at time of publication. Consult factory regarding discrepancies or inconsistencies.

# TECHNICAL DATA SHEET

MODEL 508 12-VOLT BACKUP Submersible Sump Pump System



#### **CONTROLLER ALERTS**

The Aquanot® Spin 508 is a premium high performance, self-testing battery backup pump system.

- 12 volt, highly efficient, non-corrodible pump construction supplied with 9' (2.7 m) leads
- Legs allow free-standing installation
- Quick disconnect discharge
- Aluminum seal pocket and cooling plate
- Integrated check valve

# **CONTROLLER**

The Aquanot® Spin DC Controller keeps the battery charged. The controller has many built-in features such as:

- Monitors the switches, runs the pump
- Performs self-testing diagnostics
- Uses multi-stage charging for optimal battery condition

#### **ALERTS**

- Pump cycled
- High water\*
- Battery fault
- Pump activation
- Switch fault
- Pump fault
- Power outage/restored

#### **BUTTONS**

- Alarm Silence/Reset press to silence alarms. Press and hold for three seconds to reset alarms.
- Test press to initiate pump test

### **SWITCHES**

- Reliable, vertical float switch for adjustable operation.
- High water reed sensor sold separately. P/N: 10-4830. Reed sensor provides high water signal and redundant pump run.

#### **BATTERY CASE**


The included battery case will accommodate maximum battery dimensions of 13" (330 mm) L x 7-1/2" (191 mm) W x 9-1/2" (241 mm) H and fits all group size 27, 29 and 31 batteries. Made from non-corrodible polyethylene. To use multiple batteries, order extra battery case with hookup wire (P/N 10-5184).

# **FITTINGS**

An integrated DC pump discharge check valve, additional thread-in AC pump check valve, tee, and adapter are included.

| AQUANOT® SPIN |                      |                               |                |  |  |
|---------------|----------------------|-------------------------------|----------------|--|--|
| LED INDICATOR | SOLID                | FLASHING                      | OFF            |  |  |
| System Ready  | No Faults (Green)    | AC off with no faults (Green) |                |  |  |
| Battery       | Charged (Green)      | Low Battery (Red)             | No AC<br>Power |  |  |
|               | Charging (Yellow)    |                               |                |  |  |
|               | Bad Battery (Red)    |                               |                |  |  |
| DC pump       | Pump Ran<br>(Yellow) | Pump Running<br>(Yellow)      |                |  |  |
|               |                      | Pump Fault (Red)              |                |  |  |
| Float Status  | High Water<br>(Red)* | Float Fault (Red)             |                |  |  |

\* If optional high water reed sensor is being used









# TOTAL DYNAMIC HEAD FLOW PER MINUTE @ 12.1 VOLTS

| MODEL          |        | 508          |        |
|----------------|--------|--------------|--------|
| Feet           | Meters | Gal.         | Liters |
| 5              | 1.5    | 39           | 148    |
| 10             | 3.0    | 30           | 114    |
| 15             | 4.6    | 20           | 76     |
| 20             | 6.1    | 6            | 23     |
| Shut-off Head: |        | 22ft. (6.7m) |        |

15294

Shipping weight: 17 lbs. (7.7 kg)

NOTE: Not recommended for installation with over 20' (6 m) Total Dynamic Head.

Performance chart based upon actual performance achieved with a 12 volt deep-cycle battery. Some manufacturers publish performance data based upon D.C. pump testing according to marine industry standards which can reflect a performance of 40% - 80% higher than actual battery powered performance.

See FM3166 (Aquanot® Spin 508) Installation Instructions.

Minimum pit size recommendation: 16" (40 cm) diameter X 22" (56 cm) deep. Minimum battery requirements: deep-cycle, size 27, 175 minute reserve capacity.

# **SYSTEMS**

| Model    | System                       | Warranty |
|----------|------------------------------|----------|
| 508-0005 | Aquanot® Spin 508            | 3 Years  |
| 508-0006 | Aquanot® Spin 508/M53 ProPak | 3 Years  |
| 508-0007 | Aquanot® Spin 508/M98 ProPak | 3 Years  |

Both Spin Propak Systems primary pump options come standard with Zoeller LED Plug that allows you to check for power at a quick glance.

# WARRANTY

3 years from date of purchase. Battery warranty is 3 years.

#### **BATTERY LIFE**


The estimated life of a fully charged (175 minute reserve capacity) battery when the pump is operating continuously is approximately 5.5 hours. However, most backup system pump operation is intermittent. The system will provide protection for extended periods of time dependent upon stop-start requirements and multiple battery arrangements.


#### **PERFORMANCE DATA**


Pump performance is based on the use of a fully charged 12 volt, (200-minute reserve capacity) deep-cycle battery with no deficiency and less than two years old.

# **AQUANOT® BATTERY**

- Size 31 "Wet" P/N 10-0761 (58 lbs. [27 kg]) (shipped via truckline only) 180-minute reserve capacity
- Size 27 "AGM" P/N 10-1450 (57 lbs. [26 kg]) 180-minute reserve capacity







SK3182

**▲** CAUTION

All installation of controls, protection devices and wiring should be done by a qualified licensed electrician. All electrical and safety codes should be followed including the most recent National Electrical Code (NEC) and the Occupational Safety and Health Act (OSHA).